

## Iridium Extreme Quick Start Guide



### Getting Started:

1. The Iridium Extreme device needs a clear line of sight to the sky with no obstructions. You should go outside under the sky for your phone to receive the signals.
2. Fully extend the antenna upwards.
3. To turn on your phone, press and hold down the power button on top until the phone beeps once and turns on.
4. The phone will search for a signal. This may take a few minutes. Once the screen says “Registered” you’re ready to use the device.

## Inserting the SIM card

- Remove the battery from the phone.
- Slide the SIM card into the slot, following the orientation shown in the below image.
- Reinsert the battery.
- If you are experiencing issues with the device, we recommend checking to see that the SIM is properly inserted.



## Device Setup

- Turn keypad tone off: Menu > Setup > Voice and tone > Keypad tones > No tone.
- GPS update time: Menu > Setup > Location Options > GPS Options > GPS Update Options > Real time
- Enable GPS: Menu > Setup > Location Options > GPS Options > GPS On/Off > Enable
- Tracking Frequency: Menu > Setup > Location Options > Message Options > Regular Update > Update Frequency > 10 minutes
- Panic mode functionality: Menu > Setup > Location Options > Emergency Ops > Emergency Actions > Message Only.
- Remove recipient: Menu > Setup > Location options > Emergency Options > Message Recipient > and delete \*3

## Panic Alarm



- Please ensure the device has a clear view of the sky and then press the red button for 2 seconds.
- There will be a 20 seconds countdown.
- Press Cancel to terminate the alarm.